

# INSTALLATION STEPS

**DYSO**



1. Check the stability of the structure and clean the surface. The structure must be clean of any element that make difficult the adhesion of the membrane.



2. Apply C2 S1/S2 tile adhesive with a 4/6 mm notched trowel. Apply the adhesive on small patches to prevent drying and always in the same direction. Do not install the **DYSO** membrane on hardened adhesive.



3. Place the membranes edge to edge, these must never overlap.



4. Press the **DYSO** membrane hard on the structure with the help of a plastic trowel making sure to eliminate all possible air bubbles.

**ATTENTION:** once installed, it should be checked that the membrane is totally adhered to the structure.



5. For large format tiles, it is necessary to apply adhesive also on the tiles: **DOUBLE ADHESION**.



6. Before installing the tiles, wait at least 24 h. for the adhesive on the membrane to dry. Use the adhesive recommended by the manufacturer of the tiles to adhere them to the membrane.

## Important

Since the system needs space to absorb structural movements, it is necessary **TO MAKE PERIMETRAL EXPANSION JOINTS** of at least 8 mm and **JOINTS BETWEEN THE PIECES** of at least 2 mm.